

Hearing instrument components

1. Microphone
2. Programme button/volume control
3. Battery door (not on rechargeable instruments)
4. Tubing/receiver wire
5. Speaker (with filter)



Note your instruments may look slightly different to pictured

Left and right ear markings are indicated by a **RED** for right ear and **BLUE** for left ear.



ON/OFF – The Battery

Opening the battery door turns the instrument **OFF**
Closing the battery door turns the instrument **ON**
For rechargeable instruments, placing in the charger turns them **OFF**. Taking out of the charger turns them **ON**

Turn on each MORNING and turn off each NIGHT, if wearing all day.

Daily Care

- Spray Cedis Disinfectant Spray onto a tissue and wipe earpiece.
- Brush microphones (optional).
- Store in charger (if rechargeable instruments) or place in drying cup with a Cedis drying capsule to draw moisture out.
- Remember to take out and store safely when having a bath or shower.

Weekly/monthly Care

- Change battery when it's dead (on average weekly).
- Check dome and/or filter weekly for any blockages.
- Change wax filter monthly.
- Change dome every two months.

Please call and book an appointment at your Practice if you feel you need any adjustments or any further help

Audiologist:

Practice contact number:

Troubleshooting

If your hearing instrument is **dull** or **not working**, check the battery is inserted correctly/charged up. Check for wax blockages and change domes/filters if needed.

If you're hearing instrument is **whistling**, check it is inserted correctly, change dome/filters if needed or get your Audiologist to check for wax in your ears if none of the above works.

Proper maintenance will help extend the life of your instruments & help you enjoy better hearing!